

Meet PAT Serial Number Location

2021a

Page 1




All Meet PAT water stations have 2 serial numbers.

LOCATION 1

External - At base of unit.

PERMANENT on bollard

PORTABLE on molding at base.



LOCATION 2

Internal - on brace or backing inside water station.

Graphic panels need to be removed.
Refer to instruction book.



CONFIDENTIAL | 2021